



Corner Mounting Holes

Corner Mounting Holes

Step 1: Using Cardboard template as a guide, cut out hole to fix Clipsal 2000 Series Gridplates.

Step 2: Connect wires to individual products.
Note: to comply with Standards, Clipsal 90B shroud(s) may be required to separate data/TV from power circuits.

2000H2 DRILLING TEMPLATE

Use with
2157H2G Gauge

Step 3: If either Clipsal 2155PH2 wall bracket or 2157H2 series wall box have been used, connect individual 2000 Series Gridplates to appropriate fixing positions. If either of these mounting accessories have not been installed prior to wall fitment, it is recommended to use Clipsal 2154H2 mounting clip to secure individual Gridplates. Note: before fully tightening Gridplates ensure all Gridplates are level. (Use 2157H2G metal gauge provided to assist)

Step 4: After fully tightening Gridplates, clip on 2000H2 surround.

Drill Lower Holes for
2025, 2025XA, 2015X and 2015XX

84mm Centres
Standard pattern Mounting Holes

100mm Centres

100mm Centres

Corner Mounting Holes

Corner Mounting Holes

