



Electrical identification studs, commonly known as IPA Studs for the secure marking of electrical outlets and switchboards. IPA Label Pins for the secure attachment of labels to switchboards.

How To Use

1. Select appropriate colour for phase and number for circuit
2. Fit the stud adjacent to the fuse or circuit breaker
3. Fit the same colour and number to each outlet supplied from that fuse or circuit breaker
4. Drill a neat 4mm hole, align the stud and push in
5. Polish the stud with a cloth to ensure a sharp print

