

How to remove redesigned nail plate from surface sockets.

1. Whilst holding the surface socket, insert a flat screwdriver into the slotted clip that retains the surface socket to the nail plate.
2. Twist screwdriver anticlockwise and push downwards until first clip disengages.
3. Insert flat screwdriver into other slotted clip and repeat first two steps.