

TOP SELLERS



OES

Oven Pilot Lamp E27
ES 25W 240V 300°C



OSEL25

Oven/Microwave Lamp E14
SES 25W 240V 300°C
OSEL SES 15W 300°C



OSEF

Oven Lamp - Fancy Round E14
SES 40W 240V 300°C



OEL6

Oven Lamp E27
ES 60W 240V 300°C



T2540CSES

Rangehood Lamp E14
SES 40W 240V



MW240.15W

Microwave Lamp
E17 15W 240V 300°C



CL832

25W 240V Microwave Lamp
2 x 4.8mm Terminals



F612E4

25W 240V Microwave lamp
1 x 4.8mm
1 x 6.4mm
Terminal



3150.30.03

Amber Indicator Light suits most stoves.
9mm 240V



3150.830.02

Red Indicator Light suits most stoves.
9mm 240V



3340.079.19

Momentary On/On Rocker Switch
Suit Clothes Dryer



1300.25.09

On/Off Stove Light Switch
(0534001687)



TS269

6mm Indicator Light with 200 mm leads



6006D

White Cupboard/Pantry Door Switch
10A 240V



6006DB

Black Cupboard/Pantry Door Switch
10A 240V

