

## 4062PB-EB

SWITCH 2 GANG PUSH BUTTON SATURN 4000  
SERIES INCLUDING SATURN HORIZON



### Main

Range of product	Saturn Series 4000
Product or component type	Push-button
Colour	Espresso black
Product brand	Clipsal
Device presentation	Basic element with full cover plate

### Complementary

Colour code	EB
Actuator	Push-button
Local signalling	Without light indicator
Fixing mode	By screws
Material	PVC (polyvinyl chloride)
Surface finish	Glossy
[Ue] rated operational voltage	250 V AC
Inrush current	20 A
Mounting position	Vertical

### Environment

#### Offer Sustainability

Sustainable offer status	Not Green Premium product
RoHS (date code: YYWW)	Compliant - since 1250 - Schneider Electric declaration of conformity
REACH	Reference not containing SVHC above the threshold
Product end of life instructions	Need no specific recycling operations

The information provided in this documentation contains general descriptions and/or technical characteristics of the products contained herein. This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications. It is the duty of any such user or integrator to perform the appropriate and complete risk analysis, evaluation and testing of the products with respect to the relevant specific application or use thereof. Neither Schneider Electric Industries SAS nor any of its affiliates or subsidiaries shall be responsible or liable for misuse of the information contained herein.