

Quick Overview

Combined RCD Polarity Socket Checker - 10, 15, 20, 25, 30, 35mA



Features

RCD Testers

NESCO RCD Checker

- Basic RCD and polarity socket tester
- Trip current settings 10, 15, 20, 25, 30, 35mA
- Gives true indication of RCD trip rate

Details

Part No.	S-1602
Brand	Nesco
Unit Of Measure	Each
Carton Quantity	1
Compendium Page #	558
