

## 41EPBM-VW

Clipsal Iconic Simple Pushbutton Momentary Switch for Controllink



### Main

Range	Clipsal Iconic
Product or component type	Timing relay
Device presentation	Mechanism

### Complementary

Device mounting	Flush
Actuator	Push-button
Fixing mode	Clip-in
Colour tint	Vivid white
Surface finish	Glossy
Connections - terminals	Screw terminals
Type of packing	Box
Sale per indivisible quantity	1
Remote control type	Wiser room application
[Ue] rated operational voltage	220...240 V AC 50 Hz
Operating distance	30 m
Control signal type	Controllink
Connections - terminals	Screw terminals
Number of terminals	2
Wiring configuration	2-wire
Material	PC (UL94 V-2) for top PC MAS056 (UL94 V-2) for bottom
Height	23 mm
Width	23 mm
Depth	40 mm
Embedding depth	38 mm
Standards	AS/NZS 60669.2.1

### Environment

ambient air temperature for storage	0...60 °C
ambient air temperature for operation	0...45 °C
relative humidity	0...90 %

### Offer Sustainability

Sustainable offer status	Not Green Premium product
REACH	Reference not containing SVHC above the threshold

The information provided in this documentation contains general descriptions and/or technical characteristics of the products contained herein. This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications. It is the duty of any such user or integrator to perform the appropriate and complete risk analysis, evaluation and testing of the products with respect to the relevant specific application or use thereof. Neither Schneider Electric Industries SAS nor any of its affiliates or subsidiaries shall be responsible or liable for misuse of the information contained herein.