



Fig. 19

Installing the Grille

1. Cut a hole 160 mm in diameter in eaves or outer wall. Feed ducting out through this hole and tape to the Grille baseplate.
2. Feed the ducting back through the hole so that the Grille base is against the eaves or outer wall.
3. Fix Grille base with four 6 G screws and snap fit the Grille louvres over the Grille base as shown in Fig. 19.

Replacement Lamps

The Sensation lamp surround must be removed prior to replacing lamps. Ensure lamps are screwed well in after replacement to give good electrical contact.

NOTE: Replacement with any other lamps other than those listed below may cause damage to the moulding and void the warranty.

Heat Lamps

The IXL Tastic lamps have been specially developed for best performance.

275 watts max IXL Cat no. 11300.

NOTE: Replace only with genuine IXL approved Hard Glass Infra-Red lamps.

Light Bulb

R80ES 12 W LED IXL Cat no. 12281

Light bulb is not covered by manufacturer's warranty.

NOTE: 100 W maximum light bulb on all above Tastics.