

## **ACCESSORIES**

Starter sockets can be mounted anywhere; wall, floor, ceiling etc.

Used to begin a soft wiring circuit.



ORDERING INFORMATION	
PART NO.	DESCRIPTION
SW84002**#	Single 20amp universal starter socket



ORDERING INFORMATION	
PART NO.	DESCRIPTION
SW84011**#	Single side entry 20amp starter socket



ORDERING INFORMATION	
PART NO.	DESCRIPTION
SW84011R**#	Single Rotated 20amp starter socket



ORDERING INFORMATION	
PART NO.	DESCRIPTION
SW84012**#	Double side entry 20amp starter socket

**Adaptors** These adaptors are a flexible solution for tapping off workstation power in different directions. Offering 1 input and 2 or 3 outputs simply use multiple adaptors where extra branches are required.



ORDERING INFORMATION	
PART NO.	DESCRIPTION
L3T**#	T-Piece (1 in 2 out splitter)



ORDERING INFORMATION	
PART NO.	DESCRIPTION
L3D**	D-piece (1 in 3 out splitter)

## Notes:

- Standard colours are black or white
- \*\*Denotes socket colour: BK (black), WT (white), RD (red)
- #Available in red. Additional cost applies for red.





ORDERING INFORMATION	
PART NO.	DESCRIPTION
L3R**	TAG right angle In/Out adaptor



ORDERING INFORMATION	
PART NO.	DESCRIPTION
L3U**	Tag 'U' Adaptor (1 in 1 out splitter).



ORDERING INFORMATION	
PART NO.	DESCRIPTION
L3F**	Tag 'F' Adaptor (1 in 2 out splitter).

## Tag connectors Rewireable male plug & female socket 20amp tag connectors



ORDERING INFORMATION	
PART NO.	DESCRIPTION
L3.10**	Rewireable - male tag plug 20amp



ORDERING INFORMATION	
PART NO.	DESCRIPTION
L3.20**	Rewireable - female tag socket 20amp

Notes:

Standard colours are black or white

\*\*Denotes socket colour: BK (black), WT (white)

**Node Boxes** By using simple node boxes softwire provides flexible power distribution, right from the electrical distribution board to each desk. Node boxes can be fitted in a raised floor or ceiling void. They provide maximum flexibility where there is a requirement to supply high power density at the work area. Node boxes offer customers quick and easy reconfiguration of workstations and the ability to add new workstations without the need to run new power circuits. All node boxes are fitted with the TAG coupler system complying with the latest coupler standard AS/61535.1:2003. Options such as filters, ELCBs and RCDs can be fitted at time of manufacture.

SW72110 shown

ORDERING INFORMATION	
PART NO.	DESCRIPTION
SW72105	Node box: 1 in 6 out single circuit
SW72110	Node box: 1 in 6 out dual circuit
PLEASE CALL US FOR THE MOST UP TO DATE SPECIFICATIONS AND PRICING	

SYDNEY (02) 8814 8133 | MELBOURNE (03) 9768 4833 | BRISBANE (07) 3209 7299 | PERTH (08) 9209 1166 | NEW ZEALAND (09) 582 0776 | www.cmselectra.com