



CLP501902_0001
PDL501902_0001

WiFer™

Wiser Hub Table Stand

For your safety

NOTICE

RISK OF DAMAGE TO DEVICE

Always operate the product in compliance with the specified technical data.

Failure to follow these instructions can result in equipment damage.

Getting to know the product

The Wiser Hub Table Stand (hereinafter referred to as **Table Stand**) is used as a holder for the Wiser Hub.

Using the Table Stand

Installation and removal

To install:

- ① Insert the hub into the Table Stand, observing the correct orientation.
- ② Place the hub face-down on a clean, flat surface.
- ③ Press each buckle around the hub bezel until it clicks.
- ④ Connect cables as required, then place the hub on the desired surface as shown.

To remove:

- ⑤ Disconnect the hub cables.
- ⑥ Place the hub face-down on a clean, flat surface.
- ⑦ Use a small flat-bladed screwdriver to carefully release each buckle around the hub bezel.
- ⑧ Remove the hub from the Table Stand.

Technical data

Operating temperature	-10 °C to 45 °C
Relative humidity	10% to 95%
Product dimensions (H × W × D)	86 × 54.6 × 86 mm

Trademarks

- Wiser™ is a trademark and the property of Schneider Electric SE, its subsidiaries and affiliated companies.

Customer Care

Warranty information

We warrant this product for 1 year. See **Warranty** links below.

Schneider Electric (Australia) Pty Ltd

33-37 Port Wakefield Road, Gepps Cross SA 5094

Customer Care: 13 73 28

Email: customer-care.au@se.com

Warranty:

<https://www.se.com/au/en/about-us/legal/terms-andconditions.jsp>

www.se.com

Schneider Electric (NZ) Ltd

Building 6, 60 Highbrook Drive, East Tamaka, Auckland 2013

Customer Care: 0800 652 999

Email: sales@nz.schneider-electric.com

Warranty:

<https://www.se.com/nz/en/about-us/legal/terms-andconditions.jsp>

www.se.com

