

## **UK DECLARATION OF CONFORMITY**

We: MANUFACTURER

**Schneider Electric Industries SAS** 

35 rue Joseph Monier

Rueil Malmaison 92500 - France

UK Representative Schneider Electric Limited Stafford Park 5 Telford TF3 3BL – United Kingdom

Hereby declare under our sole responsibility that the products:

Trademark	Schneider Electric
Product, Type	Pushbutton, Pilot Light and Accessories
	XA2A,ZA2E
List of reference and options	See Annex

Are in conformity with the requirements of the following directives and conformity was checked in accordance with the following standards.

UK regulation	Designated and /or International standards
The Electrical Equipment (Safety) Regulations SI 2016 No. 1101	BS EN 60947-5-1:2017 BS EN 60947-5-1:2017/AC:2020-05 Low-voltage switchgear and controlgear - Part 5-1: Control circuit devices and switching elements - Electromechanical control circuit devices
The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012 SI 2012 No. 3032	BS EN IEC 63000:2018 Technical documentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances.

Subject to correct installation, maintenance and use conforming to its intended purpose, to the applicable regulations and standards, to the supplier's instructions and to accepted rules of the art.

This declaration becomes invalid in the case of any modification to the products not authorized by us.

The guides giving requirements, details and advices for installation of products used are available on: <a href="http://www.se.com">http://www.se.com</a>

Issued at Telford United Kingdom (Representative): April 18th 2025 Signed by:

-701E992E95194EC...

Name: David Williams VP Marketing UK&I Zone UK & Ireland



## **UK DECLARATION OF CONFORMITY**

Annex - Table of product references:

Model	Description (English)
XA2AA11	Pushbutton, white, 1NO
XA2AA21	Pushbutton, black, 1NO
XA2AA25	Pushbutton, black, 1NO+1NC
XA2AA31	Pushbutton, green, 1NO
XA2AA3311	Pushbutton with symbol, white vertical line on green background, 1NO
XA2AA3341	Pushbutton with symbol, black arrow on white background, 1NO
XA2AA3351	Pushbutton with symbol, white arrow on black background, 1NO
XA2AA35	Pushbutton, green, 1NO+1NC
XA2AA41	Pushbutton,Red, 1NO
XA2AA42	Pushbutton,Red, 1NC
XA2AA4322	Pushbutton with symbol,circle on red background, 1NC
XA2AA4342	Pushbutton with symbol,red background"STOP", 1NC
XA2AA45	Pushbutton,Red, 1NO+1NC
XA2AA51	Pushbutton, Yellow, 1NO
XA2AA61	Pushbutton, Blue, 1NO
XA2AA6511	Pushbutton with symbol, "double arrow" on blue background, 1NO
XA2AC21	Φ40 mushroom head reset button, black, 1NO
XA2AC31	Φ40 mushroom head reset button, green, 1NO
XA2AC42	Ф40 mushroom head reset button, Red, 1NC
XA2AC51	Φ40 mushroom head reset button, yellow, 1NO
XA2AD21	Selector switch with 2-position self-locking short handle, 1NO
XA2AD22	Selector switch with 2-position self-locking short handle, 1NC
XA2AD25	Selector switch with 2-position self-locking short handle, 1NO+1NC
XA2AD33	Selector switch 3-position self-locking short handle, 2NO
XA2AD41	Selector switch 2-position self-resettable short handle, 1NO
XA2AD53	Selector switch 3-position resettable short handle, 2NO
XA2AG03	Key switch 3 positions self-locking, 3 positions pulled out, 2NO
XA2AG21	Key switch 2 positions self-locking, left pull-out, 1NO
XA2AG33	Key switch 3 position self-locking, middle pull-out, 2NO
XA2AG43	Key switch 2 positions self-locking, two positions pulled out, 2NO
XA2AG63	Key switch 2 positions self-reset, left pull-out, 2NO
XA2AG73	Key switch 3 position self-reset, middle pull-out, 2NO
XA2AH021	Pushbutton self-locking , black, 1NO
XA2AH031	Pushbutton self-locking , green, 1NO
XA2AH042	Pushbutton self-locking , Red, 1NC
XA2AH051	Pushbutton self-locking , Yellow, 1NO
XA2AH061	Pushbutton self-locking , Blue, 1NO
XA2AJ21	Selector switch with 2-position self-locking long handle, 1NO
XA2AJ25	Selector switch with 2-position self-locking long handle, 1NO+1NC
XA2AJ33	Selector switch 3-position self-locking long handle, 2NO
XA2AJ53	Selector switch 3-position self-resettable long handle, 2NO
XA2AS442	Emergency stop, (rotary reset), 30mm, 1NC
XA2AS542	Emergency stop,(rotary reset), 40mm, 1NC



## **UK DECLARATION OF CONFORMITY**

XA2AS642	Emergency stop, (rotary reset), 60mm, 1NC
XA2AT42	Emergency stop, (press to pull to reset), 40mm, 1NC
XA2AW31B1	Illuminated PB,White, 1NO, 24V
XA2AW31M1	Illuminated PB,White,1NO, 220V
XA2AW31Q1	Illuminated PB,White,1NO, 380V
XA2AW33B1	Illuminated PB, green, 1NO, 24V
XA2AW33M1	Illuminated PB, green, 1NO, 220V
XA2AW34B1	Illuminated PB, red, 1NO, 24V
XA2AW34B2	Illuminated PB, red, 1NC, 24V
XA2AW34M1	Illuminated PB, red, 1NO, 220V
XA2AW34M2	Illuminated PB, red, 1NC, 220V
XA2AW34Q2	Illuminated PB, red, 1NC, 380V
XA2AW35B1	Illuminated PB, Yellow, 1NO, 24V
XA2AW35M1	Illuminated PB, Yellow, 1NO, 220V
XA2AW36B1	Illuminated PB,Blue,1NO, 24V
XA2AW36M1	Illuminated PB, Blue, 1NO, 220V
ZA2EE101	Contact block 22mm faston 1NO
ZA2EE102	Contact block 22mm faston 1NC