



## USB Charging Module 30USBCM

## Quick Start Guide



### Wiring Schematic



- 1 USB Charging Module (30USBCM)
- 2 White front cap. Coloured caps are ordered separately
- 3 Terminal block
- 4 Megger Test Switchboard Label (must be placed at the switchboard)


Refer to the *USB Charging Module Installation Instructions* for additional information. The instructions can be found on the Internet at:

<http://www.clipsal.com>

<http://www.pdl.co.nz>

### WARNING: Electrical Shock Hazard


The USB Charger must be connected to an easily accessible disconnect device, RCD or MCB. Failure to comply could result in serious personal injury.



### Cap Removal and Replacement

To remove an installed cap, press on the clip and pull the cap off.

To install a cap, align the clips with the opening in the charger and press the cap until it clicks in place.




### Grid Plate Installation

Install the module with the USB logo at the bottom of the aperture.

Push the USB module into the 30 series grid plate until a click is heard.

Note: Your grid plate configuration may differ from the illustration.



### Removing a USB Module

Pry the USB module out slowly and carefully. Use only a flat-blade (standard) screwdriver, 4mm wide minimum.

Must be installed by a suitably licenced and qualified electrician only. No user serviceable parts inside. Indoor use only. For charging only.

# Warranty Statement

Schneider Electric (Australia) Pty Ltd, (Clipsal by Schneider Electric), warrants this product to be free from defects in materials and workmanship for a period of twenty (20) months from the date of installation or twenty-four (24) months from the date of purchase of this product, whichever is the earliest. The benefits conferred herein are in addition to any other rights and remedies you may have at law in respect to this product. Australian and New Zealand customers please see the notes below.

Australian Consumer Law specifies that our goods come with guarantees that cannot be excluded. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

New Zealand. This guarantee is in addition to and does not affect your rights under applicable law, except where that law expressly provides otherwise. The Consumer Guarantee Act 1993(NZ) will not apply if this product is purchased for the purpose of business.

This warranty is expressly subject to the Schneider Electric product being installed, wired, tested, operated and used in accordance with our instructions and specifications. Any alterations or modifications made to the product without our permission will void the warranty.

Schneider Electric will at its option repair, replace or refund any defective product. The cost of replacement or repair of a defective product is limited to the price of the product only. Schneider Electric will not be responsible for the cost of retrieving, removing, reinstalling, transporting (including return of the defective product to us) or re-testing a product.

How to make a claim: You shall provide Schneider Electric with adequate particulars of the defect within 28 days of the fault occurring. Contact your local Schneider Electric, PDL or Clipsal products' supplier and provide the details of the date of purchase, description of load or connections and the circumstances of the failure. Returned products must be securely packed and labeled for proper processing.

## Technical and Sales Support

For assistance with technical problems, contact your nearest Schneider Electric sales representative.

### Australia

Schneider Electric (Australia) Pty Ltd

Customer Care Australia: 1300 202 525, Fax 1300 202 556

Technical Support 1300 722 247 (Support Hotline for Australia)

Technical Support email: [cis.support@clipsal.com.au](mailto:cis.support@clipsal.com.au)

[www.schneider-electric.com.au](http://www.schneider-electric.com.au)

[clipsal.com](http://clipsal.com)

### New Zealand

Schneider Electric (NZ) Ltd

38 Business Parade South, Highbrook, East Tamaki, Manukau 2013

P.O. Box 259370 Botany, Manukau 2163

Telephone +64 9-829 0490, Fax +64 9-829 0491

After hours service hotline: 0800 735 4357 (New Zealand only)

Customer Care: 0800 652 999

Email: [sales@nz.schneider-electric.com](mailto:sales@nz.schneider-electric.com)

[www.schneider-electric.com](http://www.schneider-electric.com)

[www.pdl.co.nz](http://www.pdl.co.nz)

---

## Schneider Electric (Australia) Pty Ltd

33-37 Port Wakefield Rd

Gepps Cross, South Australia 5094

### Contact us: [clipsal.com/feedback](http://clipsal.com/feedback)

Schneider Electric (Australia) Pty Ltd, also known as Clipsal by Schneider Electric, reserves the right to change specifications, modify designs and discontinue items without incurring obligation. Every effort is made to ensure that descriptions, specifications and other information in this document are correct. However, no warranty is given in respect thereof and the company shall not be liable for any error therein.

© 2014 by Schneider Electric. All rights reserved.

Clipsal is a registered trademark of Schneider Electric Industries SA or its affiliated companies. Other trademarks are the property of their respective owners.