Catalog | February 2022



Modicon MCM

Modular safety controller



Life Is On



Modicon

Discover Modicon

Industrial Edge control for IIoT

Modicon IIoT-native edge controllers manage complex interfaces across assets and devices or directly into the cloud, with embedded safety and cybersecurity. Modicon provides performance and scalability for a wide range of industrial applications up to highperformance multi-axis machines and high-available redundant processes.

Explore our offer

- Modicon HVAC Controllers
- Modicon PLC
- Modicon Motion Controllers
- Modicon PAC
- Modicon I/O
- Modicon Networking
- Modicon Power Supply
- Modicon Safety
- Modicon Wiring

Life Is On





Quick access to product information

Get technical information about your product



Each commercial reference presented in a catalog contains a hyperlink. Click on it to obtain the technical information of the product:

- Characteristics, Dimensions and drawings, Mounting and clearance, Connections and schemas, Performance curves
- Product image, Instruction sheet, User guide, Product certifications, End of life manual

Find your catalog



- > With just 3 clicks, you can access the Industrial Automation and Control catalogs, in both English and French
- > Consult digital automation catalogs at Digi-Cat Online

Select your training



Find the right <u>Training</u> for your needs on our Global website
 Locate the training center with the selector tool, using this <u>link</u>





- Up-to-date catalogs
- Embedded product selectors,360° pictures
- Optimized search by commercial references

Life Is On



Schn

General content

Modicon MCM

M	odular safety controller
	Introduction to EcoStruxure Machine
	General overview
	Empowering industrial OEMs for the digital era page 4
	Improve efficiency page 5
	Increase profitabilitypage 5
	Reduce your time to market page 6
	Simplify integration & maintenance page 7
	Modicon MCM system
	Applications, Components, Softwarepage 8
	Certification page 9
	Flexibility and scalability page 10
	Key figures of Modicon MCM system
	Safe communication with decentralized I/O's page 11
•	Hardware
	Safety controller CPU page 12
	Safe I/O expansion modules page 13
	Safe relay output modules
	Safe speed monitoring modules page 15
	Safe communication expansion modules page 16
	Non-safe fieldbus communication modules page 16 Accessories page 17
	References
	Safety controller CPU page 18 Safe I/O expansion modules
	Safe relay output modules
	Safe speed monitoring modules
	Safe communication expansion modules
	Non-safe communication modules
	Accessories
	Software: SoSafe Configurable
-	Main features, System requirements, Safety level parameters page 21
	Function blocks
	Indexpage 24
	page 24

To be competitive in today's digital era, machine builders must be innovative. Smart machines, those that are better connected, more flexible, more efficient, and safe, are enabling machine builders to innovate in ways never before possible.

EcoStruxure, Schneider Electric's open, IoT-enabled architecture and platform, offers powerful solutions for the digital era. As part of this, EcoStruxure Machine brings powerful opportunities for machine builders and OEMs, empowering them to offer smart machines and compete in the new, digital era.

EcoStruxure Machine brings together key technologies for product connectivity and edge control on premises, and cloud technologies to provide analytics and digital services. EcoStruxure Machine helps you bring more innovation and added value to your customers throughout the entire machine life cycle.

Innovation at Every Level for Machines is full systems across three layers:

- Connected products

Our connected products for measuring, actuating, device level monitoring, and control adhere to open standards to provide unmatched integration opportunities and flexibility

Edge Control

We are IIoT-ready with a proven set of tested and validated reference architectures that enable the design of end-to-end open, connected, and interoperable systems based on industry standards. Ethernet and OPC UA facilitates IT/OT convergence meaning machine builders reap benefits from web interfaces and cloud.

Apps, Analytics & Services

Seamless integration of machines to the IT layer allows the collection and aggregation of data ready for analysis – for machine builders and end users alike this means increased uptime and the ability to find information faster for more efficient operations and maintenance.

These levels are completely integrated from shop floor to top floor. And we have cloud offer and end-to-end cybersecurity wrapped around.

EcoStruxure Machine makes it easier for OEMs/ machine builders to offer their customers smarter machines. The advent of smart machines is driven by the changing needs of end users:

- Evolving workforce
- Reducing costs
- Dynamic markets
- Shorter life cycles
- Prioritizing safety and cybersecurity

Eco Struxure Machine



* The Schneider Electric industrial software business and AVEVA have merged to trade as AVEVA Group plc, a UK listed company. The Schneider Electric and Life is On trademarks are owned by Schneider Electric and are being licensed to AVEVA by Schneider Electric.

ers	EcoStruxure Machine provides one solution for the whole machine life cycle:
	 With Smart Design & Engineering the time to market is reduced by up to 30% using our automated engineering and the simulation capabilities
r :N	- During Commissioning & Operation of the machine, resources such as energy, material and loss can be improved, and with seamless integration to the IT world efficiency can be improved by up to 40%
	Smort Maintonanaa & Sarviaaa raduaaa tha tima

- Smart Maintenance & Services reduces the time for corrective actions up to 50%

Modicon MCM Modular safety controller

Empowering industrial OEMs for the digital era

Empowering industrial OEMs for the digital era

To be competitive in today's digital era, machine builders must be innovative. Smart machines, those that are better connected, more flexible, more efficient, and safe, are enabling machine builders to innovate in ways never before possible.

- > EcoStruxure[™] Machine, our open, interoperable, IoT-enabled system architecture helps you build smarter machines and equipment faster, making your business more efficient, profitable, and sustainable.
- > EcoStruxure Machine brings together key technologies for product connectivity and edge control on premises, and cloud technologies to provide analytics and digital services.
- > EcoStruxure Machine helps you bring more innovation and added value to your customers throughout the entire machine life cycle

Safety Chain Solutions

Save time by using the ready to use, and easy to adapt certified Safety Chain Solutions

The design of the machine, the re-use of the provided documentation with wiring diagram and documented calculations, for ease with the certification process.



Solution Breakdown

- 1 Harmony XALK Emergency stop
- 2 Safety limit switches (from our partner Telemecanique sensor)
- 3 Modicon power supply 24 V DC
- 4 Modicon MCM Modular safety controller
- 5 Harmony XB4 Ø 22 mm modular metal pushbuttons, switches, and pilot lights
- 6 TeSys D contactor
- 7 Harmony XVB Ø 70 mm modular beacons and tower lights
- 8 Preventa XY2SB two-hand control station



Modicon MCM

Modular safety controller Improve efficiency

Increase profitability



To Network or Machine bus: CANopen, Ethernet/IP, Modbus Serial (RTU), EtherCAT, Modbus/TCP, Profibus DP

Modicon MCM Modular safety controller

Reduce your time to market

Reduce your time to market

Intuitive automation with **SoSafe Configurable** software

> Configuration



- > Define hardware module configuration
- > Create project configuration: drag and drop function blocks and assignment of inputs and outputs
- > Offline simulation and Online visualization & testing



- > Validate software configuration
- > View configuration behavior by offline simulation and online visualization in graphic or text views
- > Commissioning

	Modul	ar Safety	Controller	Schneider
Project Report	generated by Solaf	Configurable versi	on 1.9.4	
Project Name: 1				
User: Hane Company: Compan Dase: 01.10.200 Schematic CRC:	4 08:88:28 0780H			
Modular Safety Module CP0802 Module DI16 Not Module R04 Node Tydating from 3	Consueller: Config Configured Firmwar e O Minimum Requi O Minimum Requir emory card Disable	version: FW = 2.0) of firmware version: of firmware version: fi True	: 0.1) 0.0)	
Medular Jafety PFMd (according MTTFd (according DCavy (according	Connucliar: Safety to IEC 61508): 1, g to EN ISC 13849- g to EN ISC 13849-	Information 872-008 (1/h) 1): 172 years 1): 99.00 %		
The PTH4 valu For each Rela- load on the configuration.	e shown takes into y cutput a new va Relay cutput. No See each Relay rep	accounts the failur too must be added to recover, the PL ob ort for further deta	e rate of all the com the previous FTHS de tained for Relay o ils.	ponents with exclusion of internal relays. pending on the rwitching frequency and the utput changes according to the customer
Intention! This definition functions impl configuration 1 consider data application. User/installer	n of FL and of emented in the as been performed for all the de his task and an	the other relate fodular Safety Con terrectly. The actua rises connected to y other appent of	d parameters as not troller system by 1 FL of the ensire ap the Nodular Jafesy system configurati	forth in EN 180 1896-1 only refere to the the MSC configuration software, arraning plication and the relative parameters must consorles reystem within the soupe of the on are the exclusive responsibility of the
The final MTTI to 100 years in	d value, taking in over.	account data for al	1 the devices connect	ed to the system, must always be saturated
Resources used				
ISPOT: 124 (3/2 Function Block	4) : 2			
Total number bi	oaks: 08 (0/64)			
0550-Relay: 314 STATUS: 04 (0/2	(2/6)			
Electrical dis				
Safety Guard 2	Channel .			
Function Block Filter (ms): 0	1			
Double NC Reset Type: Aut StartTp Test: 1	CHATLE			
In1: CP0802 IN In2: CP0802 IN	UT1/Terminal17 UT2/Terminal18			
E-Juop Function Block				
Single Reset Type: Aut	enatie			
StartTp Test: 1 Connections:				
Inl: CPOBOD INT	UT2/Terminal19			
0079071: 0030				
Reset Type: Aut Response time: Dependence on 1				
function Block				
Connections: CP0802 CB3D13/1 CP0802 CB3D18/1	eminal5			
CPOSO2 Pak: Tes	erminal6 minal7			
OUTPUT2: 0580 Reses Type: Aut				
Dependence on i Function Block				
Connections: CP0002 033023/1 CP0002 033028/1	erminal9			
CPOSO2 CB3D2B/1 CPOSO2 Fbk: Tex	erminal10 minal11			
Signature				

> Use project documentation to support the wiring and safety calculation to complete the commissioning



Modicon MCM Modular safety controller Simplify integration & maintenance

Safety chain solutions





> Make your machine even safer. Easily.

Modicon MCM

Modular safety controller

System applications System components Software







Emergency Stop





Speed Monitoring Position Monitoring





Safe relay output

module

Safety controller CPU

Safe I/O expansion module







Safe speed monitoring module

Safe communication Non-safe expansion module communication module



Backplane expansion connector

6 types of modules for 6 types of functionnality



Removable memory card



SoSafe Configurable software

System applications

The Modular safety controllers Modicon MCM are designed to monitor multiple safety functions on and around a machine to minimise the risk of people accessing the dangerous moving parts of the machine such as:

- > Emergency Stop
- > Guard Monitoring
- > Perimeter Guarding
- > Position Monitoring
- > Speed Monitoring
- > Enabling Movement

Modicon MCM system provides numerous advantages compared to traditional safety modules, such as:

- > The hardware architecture of expansion modules and layout can be designed according to the machine specification and thus reduces the number of components and the footprint and wiring
- > Simplify input and output wiring by software configuration combining multiple functions together
- > Allowing machine scalability from 8 inputs and 2 dual or 4 single channel outputs and up to 128 inputs,16 dual outputs or 32 single channel outputs and up to 32 or 48 diagnostic status outputs with the expansion modules connected directly to the safety controller CPU or distributed among 6 islands
- > Connected everywhere with wide range of communication expansion modules
- Provided with intuitive software for logical configuration, offline simulation and online visualization, testing, and commissioning
- > Simplification of machine maintenance through removable memory card, which can be used to transfer the configuration to a new safety controller CPU without software

System components

Modicon MCM system is composed of:

- > A safety controller CPU which can be used as standalone or together with expansion modules
- > Safe expansion I/O modules: digital input modules, solid state and relay output modules, or mixed input/output modules
- > Safe speed monitoring modules for proximity sensors and safety encoders, safe analog inputs modules: Sin/Cos, HTL, TTL
- > Safe communication expansion modules for safe island creation
- > Non-safe communication modules: interfaces to machine fieldbus (CANopen, Profibus DP, Modbus Serial (RTU), and network (EtherCAT, Modbus/TCP, Ethernet/IP)
- > A configuration software: SoSafe Configurable
- > A memory card, available for saving configuration data for ease of maintenance and safety controller CPU setup
- > Backplane expansion connectors, for connecting the modules to the safety controller CPU

Software

The Modular safety controllers Modicon MCM are supported by a completely intuitive software: SoSafe Configurable.

The software follows a simple drag and drop function block approach to configuration and is completed with a library of configurable safety functions and logical functions as well as easy to use tools for:

- > online configuration monitoring
- > offline simulation
- > configuration validator
- > hardware device scanner
- > printable schematics and documentation

SoSafe Configurable supports a quick and easy setup of the machine. Configuration data are transferred to the safety controller CPU (XPSMCMCP0802. or XPSMCMC10804•) via a USB link (see page 21).

Guard Monitoring

Enabling movement

Modicon MCM Modular safety controller

Certification Directive and standards

System certification

The Modular safety controllers Modicon MCM are certified by TüV SÜD meeting the industrial safety standards of Category 4, PL e according to EN/ISO 13849-1 and SILcL 3 according to IEC/EN 61508 and IEC/EN 60261.

Directive and standards

Modular safety controllers Modicon MCM comply with the following directives and standards.

Directives and standards	Subject			
2006/42/EC	Machinery Directive			
2004/108/EC	Electromagnetic Compatibility (EMC)			
2006/95/EC	Low Voltage Directive (LVD)			
IEC/EN 61131-2	Programmable Controllers- Part 2: Equipment requirements and tests			
EN/ISO 13849-1	Safety of machinery: Safety-related parts of control systems – Part 1: General principles for design			
EN/ISO 13849-2	Safety of machinery: Safety-related parts of control systems – Part 2: Validation			
EN 61496-1 (Type 4)	Safety of machinery: Electro-Sensitive Protection Equipment, Part 1: General requirements and tests			
IEC/EN 62061	Safety of machinery – Functional safety of safety-related electrical, electronic and programmable electronic control systems			
EN 61508-1	Functional safety of electrical, electronic and programmable electronic safety-related systems – Part 1: General requirements			
EN 61508-2	Functional safety of electrical, electronic and programmable electronic safety-related systems – Part 2: Requirements for electrical, electronic and programmable electronic safety – related systems			
EN 61508-3	Functional safety of electrical, electronic and programmable electronic safety-related systems – Part 3: Software requirements			
IEC 61784-3	Industrial communication networks – Profiles – Part 3: Functional safety field buses – General rules and profile definitions			
C€ marking for Europe cULus marking for USA and Canada RCM marking for Australia				

Modicon MCM Modular safety controller Flexibility and scalability key figures

Flexibility and scalability

The modular safety controllers Modicon MCM provide flexibility and scalability starting with the safety controller CPU.

- It embeds 8 safety digital inputs, 2 OSSD pairs or 4 single channel OSSD, 2 or 4 status outputs. It is an appropriate solution for machines with a small number of safety functions requiring the configuration flexibility of a safety controller.
- > The safety controller CPU can be used as standalone and also with fourteen expansion modules: the system is expandable up to 128 inputs, 16 dual outputs or 32 single channel outputs and up to 32 or 48 diagnostic status outputs, ideal for machines requiring multiple safety function monitoring



Minimum size of hardware: a safety controller CPU used as standalone: 8 safety digital inputs + 2 OSSD pairs or 4 single channel OSSD + 2 or 4 status outputs



Maximum size of hardware: one safety controller CPU connected to fourteen expansion modules (1) via the backplane expansion connectors: 128 inputs + 16 OSSD pairs or 32 single channel OSSD + status outputs

Key figures of Modicon MCM system

- > Each component is compact designed: a single module dimensions are 22.5 x 99 x 114.5 mm (0.89 x 3.9 x 4.51 in), size of a typical safety relay.
- > The safe components are red colored and equipped with:
- 1 Removable spring or screw-type terminal blocks (1) for connecting the safety channels and/or the power supply
- 2 Slot for a memory card (only on safety controller)
- 3 Lr symmetrical rail locking clip
- 4 Slot for backplane expansion connector
- 5 LEDs displaying the status (I/O, communication, power supply, reset, ...)
- 6 Mini USB 2.0 connector for configuration (only on safety controller)
- 7 Protective cover
- > The non-safe components are black colored and equipped with:
- 8 Removable spring or screw-type terminal blocks (2) for connecting the power supply
- 9 LEDs displaying the status (I/O, communication, power supply, reset, ...)
- 10 Lr symmetrical rail locking clip
- Specific connector for connecting to the machine bus or network (depending on model)
- 12 Mini USB 2.0 connector for configuration

 (1) Each expansion module is provided with a multi-language instruction sheet and a backplane expansion connector (XPSMCMCN0000SG), except for XPSMCMER0002e/0004e.
 (2) Each Modicon MCM component which part number is ending with a G is equipped with spring clamp terminal block.











Non safe components: non-safe communication modules



Modicon MCM Modular safety controller Safe communication with decentralized I/O's

Safe communication with decentralized I/O's

The safety controller CPU has the possibility to monitor up to five decentralized safety related islands with a distance of 50 meters (164.04 ft) between each island on a single Safety controller CPU.

- > The safety controller CPU, the expansion modules and the safe communication expansion modules communicate safely through the use of the expansion bus performed with the backplane expansion connector which are physically located on the back of each safe module.
- > The safe communication expansion I/O modules are used in order to create safe decentralized islands (cabinets); they are connected in a line or tree configuration.
- > The order of the safe expansion modules connected with the backplane expansion connectors is not important, the configuration automatically recognizes the architecture based on the module addressing.



Safety related communication

RS 485 serial interface shielded cable (up to 50 m /164.04 ft) between two decentralized islands)

- 1 Safety controller CPU
- 2 Safe communication expansion modules (line configuration)
- 3 Safe expansion I/O modules: mixed I/O modules, Safe relay output modules, Safe speed monitoring modules for proximity sensors and safety encoders

Non-safety related communication

- 4 Non-safe communication modules: interfaces to Ethernet/IP network for non-safety related communication
- 5 Modicon TM4 communication module (Ethernet switch module) (1)
- 6 Modicon M241 logic controller (2)
- 7 Modicon TM3 expansion I/O module (3)
- (1) Consult catalog Ref. DIA3ED2140106EN
- (2) Consult catalog Ref. DIA3ED2140106EN
- (3) Consult catalog Ref. DIA3ED2140109EN



Modicon MCM Modular safety controller Safety controllers CPU



Modicon MCM Modular safety controller Safe I/O expansion modules

Safe I/O expansion modules

> Independent control of pairs of outputs > Configurable diagnostic output signals

communication expansion modules

Safe analog I/O expansion

module reference (1)

XPSMCMAI0400

XPSMCMAI0400G

Safe digital I/O expansion

1

possibilities:

The Safe expansion modules are designed for safety inputs and outputs. The safety inputs/outputs are configurable individually or in pairs, with several

> Simple diagnostics via front led signalling, configuration software,

Description

Description

> 4 configurable analog inputs 0...20 mA / 0...10 V (selectable

The XPSMCMAI0400 modules can only be configured with the

via SoSafe configurable software)

XPSMCMC10804 esafety controller CPU.

> Monitoring using line control via dedicated test outputs > Configurable filters and delays for each single input > Configurable output activation and de-activation delays

Safe analog I/O expansion modules





Safe mixed I/O expansion modules





	odule reference (1)	Description
2	XPSMCMDI0800	> 8 digital inputs
	XPSMCMDI0800G	> 4 test outputs for line control monitoring of input circuits
3	XPSMCMDI1200MT	> 12 digital inputs
	XPSMCMDI1200MTG	> 8 test outputs for line control monitoring: dedicated to monitor up to four 4-wire safety mats
4	XPSMCMDI1600	> 16 digital inputs
	XPSMCMDI1600G	> 4 test outputs for line control monitoring of input circuits
5	XPSMCMDO0002	> 2 OSSD pairs with 400mA output current
	XPSMCMD00002G	 > 2 inputs for Start/Restart interlock and external device monitoring (EDM) > 2 configurable status outputs
6	XPSMCMDO0004	> 4 inputs for Start/Restart interlock and external device
	XPSMCMDO0004G	monitoring (EDM)
		 > 4 OSSD pairs with 400mA output current > 4 configurable status outputs
7	XPSMCMDO00042A	> 4 single channel solid state OSSD high current (2 A), which
	XPSMCMDO00042AG	can be used as 4 single or 2 dual OSSD + 8 status outputs SIL 1/ PL c
8	XPSMCMDO0004S	> 4 single channel OSSD with 400mA output current
	XPSMCMDO0004SG	> 4 status outputs SIL 1/PL c The XPSMCMD00004Se modules can only be configured with the XPSMCMC10804e safety controller CPU.
9	XPSMCMDO0008C1	> 8 digital outputs SIL 1/PL c
	XPSMCMDO0008C1G	
10	XPSMCMDO0016C1	> 16 digital outputs SIL 1/PL c
	XPSMCMDO0016C1G	
	fe mixed I/O expansion odules reference (1)	Description
	XPSMCMMX0802	> 8 digital inputs
	XPSMCMMX0802 XPSMCMMX0802G	 2 OSSD pairs with 400mA output current
		> 4 test outputs for line control monitoring of input circuits
		 2 configurable status outputs 2 inputs for Start/Restart interlock and external device
		monitoring (EDM)
12	XPSMCMMX0804	> 8 digital inputs
1	XPSMCMMX0804G	> 4 single channel OSSD with 400 mA output current
		> 4 test outputs for line control monitoring of input circuits
		 > 4 configurable status outputs > 4 inputs for Start/Restart interlock and external device
		monitoring (EDM)
		The XPSMCMMX0804• modules can only be configured with the XPSMCMC10804• safety controller CPU.
	The Sefe expansion mod	ules are connected to the safety controller via the

> backplane expansion connectors.

(1) Safety I/O expansion module can be equipped with a spring clamp terminal block. The reference ends with a G.



XPSMCMeeeeeG: equipped with a spring clamp terminal block.

Modicon MCM Modular safety controller Safe relay output modules

	Four types of safe relay output modules are available.
	Safe relay output Description module reference (1) Image: Comparison of the second s
	1 XPSMCMER0002 XPSMCMER0002G > 2 forcibly guided contact safety relay output (2 NO + 1 NC) modules for 1 output without expansion bus connection 1 input for Start/Restart interlock and external device monitoring (EDM)
	2 XPSMCMER0004 XPSMCMER0004G > 4 forcibly guided contact safety relay output (2 NO + 1 NC) modules for 2 independent outputs without expansion bus connection 2 XPSMCMER0004G > 2 independent outputs without expansion bus connection > 2 inputs for Start/Restart interlock and external device monitorin
	 3 XPSMCMR00004 XPSMCMR00004G > 4 forcibly guided contact safety relay output modules with expansion bus connection > Expansion module with 4 independent safety relay outputs and the corresponding 4 inputs for the external feedback contacts (EDM) > The relay can be configured according to Category 1, 2 and 4 architectures
4 afe relay output modules	 4 XPSMCMR00004DA XPSMCMR00004DAG > 4 forcibly guided contact safety relay output modules with expansion bus connection > Expansion module with 4 independent safety relay outputs and the corresponding 4 inputs for the external feedback contacts (EDM) > The relay can be configured according to Category 1, 2 and 4 architectures > 8 configurable status outputs

(1) Safe relay output module or Safe speed monitoring module can be equipped with a spring clamp terminal block. The reference ends with a G.



XPSMCMeeeeeG: equipped with a spring clamp terminal block.

Modicon MCM Modular safety controller Safe speed monitoring modules

Safe speed monitoring modules

The safe speed monitoring modules are designed to monitor zero speed control, max speed (limited speed), speed range and direction.

- > Up to four logically selectable limited speed thresholds (freely configurable via SoSafe Configurable software) for each logical intput (axis)
- > The safe speed monitoring modules (excluding XPSMCMEN0200) are equipped with RJ45 connectors (one or two depending on the model) for encoders and terminal blocks for proximity switches
- > Max input frequency: 500 kHz for encoder monitoring and 5 kHz for proximity sensors
- The modules can be configured with incremental encoders and PNP/NPN proximity > switches as described below:

	fe speed monitoring odule reference (1)	Description	Connector type
1	XPSMCMEN0100HT XPSMCMEN0100HTG	 > 1 input for HTL encoder + 1 or 2 proximity switches 	1x RJ45 (ENC1) and terminal blocks for proximity sensor wiring
2	XPSMCMEN0100SC XPSMCMEN0100SCG	 > 1 input for Sin/Cos encoder + 1 or 2 proximity switches 	1x RJ45 (ENC1) and terminal blocks for proximity sensor wiring
3	XPSMCMEN0100TT XPSMCMEN0100TTG	 > 1 input for TTL encoder + 1 or 2 proximity switches 	1x RJ45 (ENC1) and terminal blocks for proximity sensor wiring
4	XPSMCMEN0200 XPSMCMEN0200G	> 2 inputs for proximity switches	Terminal blocks for proximity sensor wiring
5	XPSMCMEN0200HT XPSMCMEN0200HTG	 > 1 or 2 inputs for HTL encoders + 1 or 2 proximity switches 	2x RJ45 (ENC1/ENC2) and terminal blocks for proximity sensor wiring
6	XPSMCMEN0200SC XPSMCMEN0200SCG	 > 1 or 2 inputs for Sin/Cos encoders + 1 or 2 proximity switches 	2x RJ45 (ENC1/ENC2) and terminal blocks for proximity sensor wiring
7	XPSMCMEN0200TT XPSMCMEN0200TTG	 > 1 or 2 inputs for TTL encoders + 1 or 2 proximity switches 	2x RJ45 (ENC1/ENC2) and terminal blocks for proximity sensor wiring

> The safe speed monitoring modules are connected to the safety controller via the backplane expansion connector.

(1) Safe relay output module or Safe speed monitoring module can be equipped with a spring clamp terminal block. The reference ends with a G.













Safe speed monitoring modules



XPSMCM eeeeeG: equipped with a spring clamp terminal block.

Modicon MCM

Modular safety controller Safe communication expansion modules Non-safe communication modules

Safe communication expansion modules

The safe communication expansion modules enable the connection of safety controller CPU (XPSMCMCP0802 or XPSMCMC10804 e) with the expansion modules placed remotely (≤ 50 m (≤ 164 ft)).

Using RS 485 shielded cable, the two modules (XPSMCMCO0000S1 and XPSMCMCO0000S2) placed at the desired distance can be linked together thus joining the expansion modules to the safety controller CPU.

- > XPSMCMC00000S2 safe communication expansion module has two independent connection channels; typically used in between two XPSMCMC00000S1 modules.
- > XPSMCMC00000S1 safe communication expansion module has one channel connection for transmitting/receiving data and must be connected as the first or last module.
- > Up to five islands can be created using the safe communication modules with a total length of 250 meters (820.2 ft) and a maximum of 50 meters (164 ft) between two safe communication modules. The system response time does not change with the use of the safety communication modules.

Safe communication expansion Description

- module reference (1)
 - XPSMCMC00000S1 > 1 connection interface: single channel transmitter/receiver (2) XPSMCMC00000S1G
- 2 XPSMCMC00000S2 > 2 connections interface: dual channel transmitter/receiver XPSMCMC00000S2G

Non-safe fieldbus communication modules

The non-safe communication modules are designed for diagnostics connection and data communication purposes to machine field bus or network systems.

Non-sa referei	afe communication modu nce (1)	le Machine bus/network interface	Connector type	Number of connectors
1	XPSMCMC00000CO XPSMCMC00000COG	> CANopen	SUB-D 9 contacts (female)	1
<mark>2</mark> (3)	XPSMCMCO0000EC XPSMCMCO0000ECG	> EtherCAT	RJ45 (in/out)	2
<mark>3</mark> (3) (4)	XPSMCMCO0002EC XPSMCMCO0002ECG	> EtherCAT	RJ45 (in/out)	2
4 (3)	XPSMCMCO0000EI XPSMCMCO0000EIG	> Ethernet/IP	RJ45 (in/out)	1
<mark>5</mark> (3) (4)	XPSMCMCO0002EI XPSMCMCO0002EIG	> Ethernet/IP	RJ45 (in/out)	2
<mark>6</mark> (3)	XPSMCMCO0000EM XPSMCMCO0000EMG	> Modbus/TCP	RJ45 (in/out)	1
7 (3)	XPSMCMCO0002EM XPSMCMCO0002EMG	> Modbus/TCP	RJ45 (in/out)	2
8	XPSMCMCO0000MB XPSMCMCO0000MBG	> Modbus Serial (RTU)	RJ45	1
9	XPSMCMCO0000PB XPSMCMCO0000PBG	> Profibus DP	SUB-D 9 contacts (male)	1

> The non-safe communication modules are connected to the safety controller via the backplane expansion connector. Each of them have a mini USB 2.0 connector for configuration

> Only one non-safe communication module type can be connected on a safety controller.

(1) Safe communication expansion module and non-safe communication module can be equipped with a spring clamp terminal block. The reference ends with a G.

(2) End of the network or Start of the network if connected to a single RS 485 cable.

(3) The modules XPSMCMC00000E have the process image mapping of the FW V 2.1.3.
 The modules XPSMCMC00002E have the process image mapping of the FW V 2.1.4 and onwards.

(4) Available in the second quarter of 2022.











XPSMCM ... equipped with a spring clamp terminal block.

Modicon MCM Modular safety controller

Accessories

Scheider -XPBACHIME000 THIS SDE INTERNAL

Memory card



Backplane Expansion connector

Accessories

Memory card

XPSMCMME0000 removable memory card is used to save configuration data for subsequent transfer to a new device without using a PC.

- > The configuration in the XPSMCMME0000 overwrites any other configuration present on the safety controller CPU (XPSMCMCP0802• or XPSMCMC10804•), replacing the old configuration contained in the card by the newest one.
- > This configuration replacement function can be disabled on the safety controller via **SoSafe Configurable** software.
- > Overwrite operations are recorded in chronological order in the safety controller CPU LOG file.
- Backplane expansion connector

XPSMCMCN0000SG backplane expansion connector provides a safe

- communication between safe expansion components and the safety controller CPU.
 Safety controller CPU (XPSMCMCP0802• or XPSMCMC10804•) requires the purchase of the backplane expansion connector.
- > Expansion modules are provided with one backplane expansion connector.
- > Use references XPSMCMCP0802BC, XPSMCMCP0802BCG, XPSMCMC40004P and XPSMCMC40004PC where I/O supervises in the text of tex of text of text of text of text of text of tex o

XPSMCMC10804B and XPSMCMC10804BG when I/O expansion is required. The references includes both the safety controller and backplane expansion connector.

Configuration cable

TCSXCNAMUM3P cable is used for software configuration between a PC, the safety controller, and to the fieldbus communication modules.

- > Length 3 m (9.84 ft)
- > It is equipped with USB connectors: USB A and USB mini B

Safe communication cable

RS 485 serial interface shielded cable are used between the safe communications expansion modules to create up to 6 decentralized safety related islands > Available longths: 10 to 50 m (22.81 to 164.04 ft)

> Available lengths: 10 to 50 m (32.81 to 164.04 ft)

Encoder splitter cable

The encoder splitter cable enables the connection of an embedded encoder within the MC-4 Servo Drives (PacDrive M motion system) as well for Lexium 32, Lexium 52 and Lexium 62 servo drives to the speed monitoring module of the modular safety controller > Available lengths: 1 to 5 m (3.3 to 16.4 ft)

References

Modicon MCM

Modular safety controller Safety controllers CPU Safe I/O expansion modules

> Weight kg//b 0.250 0.55

> Weight kg//b 0.260 0.57

Weight kg/lb

> 0.164 0,36

0.230 0.51

0.250 0.55

0.250 0.55

0.230 0.51

0.250 0.55

0.150 0.33

0.138 0,30

0.130 0,28

0.145 0,31

0.250 0.55

0.150 0.33

		Safety con	trollers CPU				
1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Mi Lance	Description	Inputs	Outputs	Terminal	Reference	١
	C XPSMCMC10804			· · ·	block type		
		Safety controller CPU	s8 safety-related digital inputs	2 OSSD pairs + 4 test outputs + 2 status outputs	Screw	XPSMCMCP0802	_
			+ 2 for Start/Restart interlock		Spring clamp	XPSMCMCP0802G	i
Contraction of the second s			8 safety digital inputs	4 single channel OSSD	Screw	XPSMCMC10804	-
XPSMCMCP0802BC			+ 4 for Start/Restart interlock	with 400 mA output current + 4 configurable status outputs	Spring clamp	XPSMCMC10804G	-
the second	Wiger .	Description		Composition	Terminal block type	Reference	١
	None Party and the second	Safety controller backplane expans	s CPU combined with ion connector	XPSMCMCP0802 + XPSMCMCN0000SG	Screw	XPSMCMCP0802BC	
				XPSMCMC10804 + XPSMCMCN0000SG	_	XPSMCMC10804B	-
XPSMCMMX0802	s-spritter]			XPSMCMCP0802G + XPSMCMCN0000SG	Spring clamp	XPSMCMCP0802BCG	i
	XPSMCMMX0804			XPSMCMC10804G + XPSMCMCN0000SG	_	XPSMCMC10804BG	-
02030	-	Safa I/O ax	pansion module			_	
And the second s	1. A. C.	Description	Inputs	Outputs	Terminal	Reference	١
			O expansion modu	· ·	block type		
Balante Statypeider		Safe analog I/O	4 configurable analog	_	Screw	XPSMCMAI0400 (1)	
	The seguriter	expansion modules	inputs 020 mA / 010 V (selectable via		Spring clamp	XPSMCMAI0400G (1)	-
XPSMCMAI0400		moduloo	SoSafe configurable software)				
Mr. Samon	XPSMCMDI0800	Safe digital I/	O expansion modu	los			
the second	Sa ex mo	Safe digital I/O	8 digital inputs	4 test outputs	Screw	XPSMCMDI0800	
		expansion modules			Spring clamp	XPSMCMDI0800G	-
			12 digital inputs	8 test ouputs for 4 wires safety Mats	Screw	XPSMCMDI1200MT	
The second					Spring clamp	XPSMCMDI1200MTG	-
- Line			16 digital inputs	1	Screw	XPSMCMDI1600	
XPSMCMDI1600					Spring clamp	XPSMCMDI1600G	-
	XPSMCMDI1200MT		2 for Start/Restart	2 OSSD pairs +	Screw	XPSMCMD00002	
2000	William .		interlock	2 configurable status outputs	Spring clamp	XPSMCMDO0002G	-
			4 for Start/Restart interlock	4 OSSD pairs +	Screw	XPSMCMDO0004	
				4 configurable status outputs	Spring clamp	XPSMCMDO0004G	-
a signific			_	4 single channel solid state	Screw	XPSMCMD000042A	
XPSMCMD00002					OSSD high current (2 A), which can be used as 4		XPSMCMDO00042AG
	XPSMCMDO0004			single or 2 dual OSSD + 8 status outputs SIL 1/ PL c			
2000	1 4 9 5 6 9 M			4 single channel OSSD	Screw	XPSMCMDO0004S (1)	
and a second	1. S.			with 400mA output current 4 status outputs SIL 1/PL c	Spring clamp	XPSMCMDO0004SG (1)
				8 digital outputs SIL 1/PL c	Screw	XPSMCMDO0008C1	
(s-gyrider)					Spring clamp	XPSMCMDO0008C1G	-
XPSMCMD000042A	Seggeider			16 digital outputs SIL 1/	Screw	XPSMCMDO0016C1	
XI OMOMBOOOO+2A	XPSMCMDO0004S			PLc	Spring clamp	XPSMCMDO0016C1G	-
		Safe mixed I/	O expansion modu	les			
and	Safe mixed I/O expansion modules	8 digital inputs + 2 for Start/Restart interlock	2 OSSD pairs + 4 test outputs + 2 status outputs	Screw Spring clamp	XPSMCMMX0802 XPSMCMMX0802G	-	
costor - 4		2 . T	8 digital inputs	4 single channel OSSD	Screw	XPSMCMMX0804 (1)	
XPSMCMD00008C1			+ 4 for Start/Restart interlock	with 400 mA output current + 4 test outputs for line control monitoring of input circuits + 4 configurable status outputs	Spring clamp	XPSMCMMX0804G (1,)
	VDSMCMDO0016C1						

XPSMCMDO0016C1

(1) XPSMCMAI0400•, XPSMCMDO0004S• and XPSMCMMX0804• modules can only be configured with XPSMCMC10804• safety controller CPU.

References (continued)

Modicon MCM

Modular safety controller Safe relay output modules Safe speed monitoring modules

Safe communication expansion modules



XPSMCMER0002



Safe relay o	utput modules				
Description	Inputs	Outputs	Terminal block type	Reference	Weight kg/lb
Safe relay output modules (without	1 for Start/Restart interlock	2 relays for 1 output (2 NO + 1 NC)	Screw	XPSMCMER0002	0.250 0.55
expansion bus connection)			Spring clamp	XPSMCMER0002G	_
	2 for Start/Restart interlock	4 relays for 2 independan outputs	t Screw	XPSMCMER0004	0.300 0.66
	(4 NO + 2 NC)	Spring clamp	XPSMCMER0004G	_	
Safe relay output modules	4 for Start/Restart interlock	4 relays	Screw	XPSMCMR00004	0.300 0.66
(wiring with the backplane expansio connector)	n		Spring clamp	XPSMCMRO0004G	_
,	4 for Start/Restart interlock	4 relays with 8 status outputs	Screw	XPSMCMR00004DA	0.330 0.73
			Spring clamp	XPSMCMR00004DAG	_

XPSMCMR00004DA

XPSMCMER0004



XPSMCMEN0100HT



XPSMCMEN0100TT





XPSMCMEN0100SC

XPSMCMEN0200



XPSMCMEN0200SC



XPSMCMEN0200TT





Safe speed	d monitoring modules			
Description	Inputs (number & type)Connector type	Terminal block type	Reference	Weight kg/lb
Safe speed monitoring	 1 HTL encoder and 2 proximity sensor inputs (1) 	Screw	XPSMCMEN0100HT	0.280 0.62
modules	■ 1x RJ45 (ENC1)	Spring clamp	XPSMCMEN0100HTG	
	1 Sin/Cos encoder and 2 proximity sensor inputs (1)	Screw	XPSMCMEN0100SC	0.280 0.62
	∎ 1x RJ45 (ENC1)	Spring clamp	XPSMCMEN0100SCG	
	 1 TTL encoder and 2 proximity sensor inputs (1) 	Screw	XPSMCMEN0100TT	0.280 0.62
	■ 1x RJ45 (ENC1)	Spring clamp	XPSMCMEN0100TTG	
	 2 inputs for proximity switches (1) None 	Screw	XPSMCMEN0200	0.230 0.51
		Spring clamp	XPSMCMEN0200G	
	Up to 2 HTL encoders and 2 proximity sensor inputs (1)	Screw	XPSMCMEN0200HT	0.300 0.66
	■ 2x RJ45 (ENC1/ENC2)	Spring clamp	XPSMCMEN0200HTG	_
	Up to 2 Sin/Cos encoders and 2 proximity sensor inputs (1)	Screw	XPSMCMEN0200SC	0.300 0.66
	2x RJ45 (ENC1/ENC2)	Spring clamp	XPSMCMEN0200SCG	_
	Up to 2 TTL encoders and 2 proximity sensor inputs (1)	Screw	XPSMCMEN0200TT	0.300 0.66
	■ $2x RJ45$ (ENC1/ENC2)	Spring clamp	XPSMCMEN0200TTG	

Safe com	nunication expansion mod	lules
Description	Characteristics	Terminal block type

		block type		kg/lb
Safe RS 485 bus expansion module	1 connection interface: single channel transmitter/ receiver network connection	Screw	XPSMCMC00000S1	0.300 0.66
for remote extension		Spring clamp	XPSMCMC00000S1G	
	2 connections interface: dual channel transmitter/ receiver network connection	Screw	XPSMCMC00000S2	0.300 0.66
		Spring clamp	XPSMCMC00000S2G	

(1) Proximity sensor connection via terminal blocks.

XPSMCMC00000S1

Weight

Reference

Modicon MCM

Modular safety controller Non-safe communication modules Accessories



Modicon MCM Modular safety controller SoSafe Configurable software



SoSafe Configurable software



Safety controller CPU



Text visualization



Graphic visualization

The I/O MONITOR allows the real-time monitoring of all the I/O of a Modicon MCM system and the diagnostic information about a working system.

SoSafe Configurable software

SoSafe Configurable is used to create complex logical conditions using logical operators and safety functions, such as muting, timer, counters, memories, etc. via a simple and intuitive graphic configuration interface.

Configuration data are transferred to the safety controller CPU (XPSMCMCP0802• or XPSMCMC10804•) via a USB link.

- > Safety controller CPU have a mini USB 2.0 connection to connect to a PC where the SoSafe Configurable software is installed.
- > An application held on a safety controller CPU can be saved on the memory card (optional) for fast transfer of the configuration data to other modules.

Password

The software is protected with 2 levels of alphanumerical password (max 8 characters.)

- > The level 1 password is an operation and maintenance password. It allows only to view the LOG file, the composition of the system and use the real time MONITOR.
- > The level 2 password enables all features of the software to be accessible. Allowing to load, modify, save, and download (from the PC to safety controller CPU) a project configuration.

LOG file (Level 1 password).

A log file with the creation date and CRC checksum (4-digit hexadecimal identification) of a project are stored in the safety controller.

- > A logbook can record up to 5 consecutive events, after which these are overwritten, starting from the least recent event.
- > The log file can be visualized using the icon in the standard tool bar.

Main features

SoSafe Configurable software main features are:

- > "Drag & Drop" configuration of all safety functions and logic
- > Functional validation of design
- > 2-level password management for the prevention of unauthorised access and therefore of incidental modifications or tampering with system configuration
- > Configuration of parameters of function blocks, for example:
 - single or dual channel NO or NC inputs
 - test outputs for monitoring of electro-mechanical input devices and photocells and related electrical connections
 - automatic, manual and monitored manual restart
 - synchronisation control of two channels
 - contact anti-rebound filters and timers
- start-up test.
- > Single or bi-directional 2 or 4 sensor muting function blocks
- > Online monitoring of I/O status
- > Offline simulation of configuration
- > Project documentation and schematics

System requirements

- SoSafe Configurable is downloadable from our website. It runs on PC with:
- > RAM: 256 MB
- > Hard disk: free space > 300 MB
- > USB connector: 1.1 or 2.0
- > Microsoft Windows® 10, Microsoft Windows® 7 32 and 64-bit , Microsoft Windows® 8.1 32 and 64-bit
- > Microsoft Framework 3.5 (or higher).
- > Available language: English

Safety level parameters			
Parameter	Value	Standard	
PFH _d	≥ 10 ⁻⁸ PFH _d < 10 ⁻⁷	IEC 61508	
SIL	3	120 01300	
SILCL	3	IEC 62061	
Туре	4	EN 61496-1	
PL	е		
DCavg	High		
MTTF _d (years)	100 years	ISO 13849-1	
Category	4		
Operation life time	20 years		

Modicon MCM Modular safety controller SoSafe Configurable software Function blocks





















Function blocks	
Input objects	
E-STOP	Verifies an emergency stop device inputs status. If the emergency stop button has been pressed (contacts open) the output is 0. If not the output is 1.
SAFETY GUARD	Verifies a mobile guard or safety gate device input status. If the mobile guard or safety gate is open, the output is 0. Otherwise the output is 1.
ENABLE (enable key)	Verifies a manual key device Input status. If the key is not turned the output is 0. Otherwise the output is 1.
LIGHT CURTAIN (optoelectronic safety light curtain laser scanner)	Verifies an optoelectronic safety light curtain (or laser scanner) inputs state. If the area protected by the /light curtain is occupied, (light curtain outputs 0) the output is 0. Otherwise, with the area clear and outputs to 1 the output of this function block is 1.
FOOTSWITCH (safety pedal)	Verifies the status of the inputs of a safety pedal device. If the pedal is not pressed the output is 0. Otherwise the output is 1.
PHOTOCELL (safety photocell)	Verifies the status of the inputs of an optoelectronic safety photocell. If the beam of the photocell is occupied (photocell output 0) the output is 0. Otherwise with the beam clear and an output of 1 the output is 1.
SELECTOR SWITCH	Verifies the status of the inputs from a mode selector (up to 4 inputs). If only one input is 1 the corresponding output is also 1. In all other cases, and thus when all inputs are 0 or more than one input is 1 all the outputs are 0.
TWO HAND CONTROL	Verifies the status of the inputs of a two hand control switch. If both the buttons are pressed within 50 msec the output is 1. Otherwise the output is 0.
SAFETY MAT (safety mat or safety edge)	Verifies the status of the inputs of a safety mat or safety edge. If a person stands on the mat the output is 0. Otherwise, with the mat clear, the output is 1. Test outputs must be used. Cannot be used with 2-wire mats and termination resistance mats.
ENABLE SWITCH	Verifies the input Inx status of an Enabling Switch. In the event that the switch is not pressed (position 1) or completely pressed (position 3), the OUTPUT will be 0. If it is pressed in the middle (position 2), the output will be 1.
TESTABLE SAFETY DEVICE	The function can be used with every generic input either one or two channels and either NO or NC contacts.
SENSOR	Verifies the status of the input of a sensor (non-safety sensor). If the beam of the sensor is occupied (sensor output 0) the output is 0. Otherwise, with the beam clear and an output of 1 then the output is 1.
LOCK FEEDBACK	Verifies the feedback from the Guardlock solenoid generating a 1 when the guardlock is locked and (when open.
SWITCH	Verifies the input status of a pushbutton or switch (non-safety switch). If the pushbutton is pressed the output is 1. Otherwise, the output is 0.
SOLID STATE DEVICE	Verifies INx input status. If the the inputs are High the output is 1 else 0.
FIELDBUS INPUT	Verifies the fieldbus input value signals (up to 8 bits) from the machine control unit via the field-bus module. The signal is connected directly into the configuration.
LLO	0 input value.
LL1	1 input value.
NETWORK_IN	Used to connect the network inputs to the NETWORK function block. When the inputs are set to TRUE, the associated output is set to TRUE.
Analog Monitoring	
ANALOG INPUT	Configures the single or redundant analog input 4 20 mA or 0 0V. It is available with XPSMCMC10804e safety controller CPU and XPSMCMAI0400e Safe I/O expansion module.
ANALOG DIVISION	Allows the arithmetic division of the values of two inputs. The inputs can be single or redundant. ANALOG DIVISION allows also the configuration of one THRESHOLD COMPARATOR (or one WINDOW COMPARATOR) and an ALERT COMPARATOR.
Speed Monitoring	
ZERO SPEED MONITORING	Verifies the speed of a device generating an output 1 when the speed is 0. If the speed is different fro 0 generates an output 0.
ZERO AND MAX SPEED MONITORING	Verifies the speed of a device generating an output Zero = 1 when the speed is 0. If the speed is different from 0 generates an output Zero = 0. Moreover, this block verifies the speed of a device generating an output Over = 0 when the speed is over a defined threshold.
MAXIMUM SPEED MONITORING	G Verifies the speed of a device generating an output 0 when the speed is over a defined threshold. Verifies the speed of a device generating an output 1 when the speed is inside a defined range.
	OSSD comiconductor DND cofety static output single or duel shannel (single shannel 4004)
SINGLE-DOUBLE OSSD (safety outputs)	OSSD semiconductor PNP safety static output single or dual channel (single channel, 400mA) The outputs can operate independently or in pairs. Each OSSD single or dual channel can work in both AUTO/Manual restart mode and can perform the EDM of external relays or contactors using the dedicated RESTART_FBK input.
STATUS (signal output)	The Status outputs are non-safety diagnostic outputs which can be used to provide the status of part of the logic within the configuration.
RELAY	Used with the XPSMCMRO0004 modules and is configurable to Category 1, 2 and 4.
FIELDBUS PROBE OUTPUT	Used to provide the status of part of the logic within the configuration to a PLC or HMI device.

Modicon MCM Modular safety controller SoSafe Configurable software Function blocks

























Function blocks	
Muting operators	
MUTING "L"	Monitors the 2 muting sensors along with the light curtain for L Muting setup.
with 2 Muting sensors, only for one-way openings	
MUTING "T" with 2 Muting sensors for two-way openings	Monitors the 2 muting sensors along with the light curtain for T Muting setup.
MUTING "SEQUENTIAL" with 4 Muting sensors for two-way openings	Monitors the 4 muting sensors along with the light curtain for sequential Muting setup.
MUTING "CONCURRENT" with 4 Muting sensors for two-way openings	Monitors the 4 muting sensors along with the light curtain for concurrent Muting setup.
MUTING OVERRIDE	Forces the output high allowing to remove the material obstructing the gate. Two different operations are available: Manual action with hold to run, and Automatic with pulse command.
Analog operators	
ANALOG COMPARATOR	Works as a comparator of an analog signal connected only with XPSMCMC10804 • controller.
MATH	Calculates the sum or the difference of analog signals coming from ANALOG INPUT blocks. This wo only with XPSMCMC10804• controller.
EQUALITY CHECK	Verifies if two analog inputs are equal within a selectable tolerance. This works only with XPSMCMC10804e controller.
General/Miscellaneous	
SERIAL OUTPUT	Transfers the state of up to a maximum of 8 inputs into a serial line data output.
NETWORK	Allows to distribute in a local network Stop and Reset commands between safety controller CPU.
INTERPAGE IN AND	Memory bit which are reused from inputs to multiple outputs.
INTERPAGE OUT RESET	Initiates a system reset when there is an OFF-ON-OFF transition on the corresponding input which
Memory operators	lasts less than 5 s.
D FLIP FLOP	Saves the previously set status on output Q on the clock rising edge.
SR FLIP FLOP	Provides an output Q at 1 with Set, 0 with Reset.
T FLIP FLOP	Changes state whenever the input triggered. If the T input is low, the flip-flop holds the previous va
T FLIP-FLOP	Switches the Q output at each rising edge of the T input (toggle).
USER RESTART MANUAL	Used to create a common reset for multiple input functions on rising edge of the reset input.
MACRO RESTART MANUAL	Used to combine a logic gate of your choice with the USER RESTART MANUAL function block according to the pre-defined truth table.
USER RESTART MONITORED	Used to create a common reset for multiple input functions on rising edge and falling edge of the reinput.
MACRO RESTART MONITORED	Used to combine a logic gate of your choice with the USER RESTART MONITORED function bloc according to the pre-defined truth table.
Counter operator	
COUNTER	Generates a pulse as soon as the set count is reached.
Timer operators	
PULSE GENERATOR	Generates a clock signal output with the desired period if the input In is 1.
MONOSTABLE	Generates a level 1 output activated by the rising edge of the input and remains in this condition fo the set time.
MONOSTABLE_B	Generates a 1 (TRUE) output activated by the rising/falling edge of the input and remains in this condition for the set time.
PASSING MAKE CONTACT	The output follows the signal on the input. However, if this is 1 for longer than the set time, the output changes to 0.
DELAY	Applies a delay to a signal by setting the output to 1 after the set time, against a change in the level the input signal.
	Applies a delay to a signal by setting the output to 0 (FALSE) after the set time, the delay is set at a falling edge of the input signal.
	Generates a signal (TRUE or FALSE) for a user-definable period.
Logical operators	Debume 4 as suboublif all the insula such
AND	Returns 1 as output if all the inputs are 1
NAND	Returns 0 as output if all the inputs are 1.
NOT	Inverts the logical status of the input.
OR	Returns 1 as output if at least one of the inputs is 1.
NOR	Returns 0 as output if at least one of the inputs is 1.
XOR	Returns 0 as output if all the inputs are in the same logical status.
XNOR	Returns 1 as output if all the inputs are in the same logical status.
MULTIPLEXER	Forwards the signal of the inputs to the output according to the Sel selection.
	Enables the grouping of two or three logic gates. The result of the third logic gate provided at the output.
IntFbk	
INTFBK IN & INTFBK OUT	Configures up to 8 internal feedback loops. Possible to connect the output of a function block by us the IntFbk_Out operator to the input of a function block by using the IntFbk_In operator. This works

Schneider Gelectric

Index

Modicon MCM

Modular safety controllers

Product reference index

Т	
TCSXCNAMUM3P	20
TSXESPP3001	20
TSXESPP3003	20
TSXESPP3005	20
TSXESPPM001	20
TSXESPPM005	20
TSXSCMCN010	20
TSXSCMCN025	20
TSXSCMCN050	20

x	
XPSMCMAI0400	13 18
XPSMCMAI0400G	13
XPSMCMC10804	18 12
XPSMCMC10804B	18 12
	18
XPSMCMC10804BG	12 18
XPSMCMC10804G	12 18
XPSMCMCN0000SG	20
XPSMCMC00000CO	16 20
XPSMCMC00000COG	16
XPSMCMCO0000EC	20 16
XPSMCMC00000ECG	20 16
	20
XPSMCMCO0000EI	16 20
XPSMCMCO0000EIG	16 20
XPSMCMC00000EM	16 20
XPSMCMC00000EMG	16
XPSMCMC00000MB	20 16
	20
XPSMCMCO0000MBG	16 20
XPSMCMCO0000PB	16 20
XPSMCMC00000PBG	16 20
XPSMCMCO0000S1	16
XPSMCMCO0000S1G	19 16
	19
XPSMCMCO0000S2	16 19
XPSMCMCO0000S2G	16 19
XPSMCMCO0002EC	16
XPSMCMCO0002ECG	20 16
XPSMCMCO0002EI	20 16
XPSMCMC00002EIG	20
	16 20
XPSMCMCO0002EM	16 20
XPSMCMC00002EMG	16 20
	20

XPSINCINCP0802	12 18
XPSMCMCP0802BC	12 18
XPSMCMCP0802BCG	12 18
XPSMCMCP0802G	12
XPSMCMDI0800	18 13
XPSMCMDI0800G	18 13
XPSMCMDI1200MT	18 13
XPSMCMDI1200MTG	18 13
XPSMCMDI1600	18 13 18
XPSMCMDI1600G	13 18
XPSMCMD00002	13 18
XPSMCMD00002G	13 18
XPSMCMD00004	13 18
XPSMCMDO00042A	13 18
XPSMCMD000042AG	13
XPSMCMD00004G	18 13
XPSMCMD00004S	18 13 18
XPSMCMD00004SG	13 18
XPSMCMD00008C1	13 18
XPSMCMDO0008C1G	13 18
XPSMCMD00016C1	13 18
XPSMCMD00016C1G	13 18
XPSMCMEN0100HT	15 19
XPSMCMEN0100HTG	15 15 19
XPSMCMEN0100SC	15 15 19
XPSMCMEN0100SCG	15 15 19
XPSMCMEN0100TT	15 15 19
XPSMCMEN0100TTG	15 15 19
XPSMCMEN0200	15 15 19
XPSMCMEN0200G	19 15 19
XPSMCMEN0200HT	19 15 19
XPSMCMEN0200HTG	19 15 19
XPSMCMEN0200SC	15
XPSMCMEN0200SCG	19 15 10
XPSMCMEN0200TT	19 15 10
	19

XPSMCMCP0802

12

XPSMCMEN0200TTG	15 19
XPSMCMER0002	14
	19
XPSMCMER0002G	14
	19
XPSMCMER0004	14
	19
XPSMCMER0004G	14
	19
XPSMCMME0000	20
XPSMCMMX0802	13
	18
XPSMCMMX0802G	13
	18
XPSMCMMX0804	13
	18
XPSMCMMX0804G	13
	18
XPSMCMRO0004	14
	19
XPSMCMRO0004DA	14
	19
XPSMCMR00004DAG	14
	19
XPSMCMRO0004G	14
	19

Life Is On Schneider



Learn more about our products at <u>www.se.com</u>

The information provided in this documentation contains general descriptions and/or technical characteristics of the performance of the products contained herein. This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications. It is the duty of any such user or integrator to perform the appropriate and complete risk analysis, evaluation and testing of the products with respect to the relevant specific application or use thereof. Neither Schneider Electric nor any of its affiliates or subsidiaries shall be responsible or liable for misuse of the information contained herein.

Design: Schneider Electric Photos: Schneider Electric

Schneider Electric Industries SAS Head Office 35, rue Joseph Monier - CS 30323 F-92500 Rueil-Malmaison Cedex France

DIA3ED2140901EN February 2022 - V5.0