






S1A4559111




VW3A3601 / VW3A3608
VW3A3616 / VW3A3627
VW3A3619 / VW3A3647



VW3A3609
VW3A3628
VW3A3725
VW3M3301



VW3A3607
VW3A3618



VW3A3720
VW3A3721
VW3M3308
VW3A3530D

⚡ ⚠ DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

- Only appropriately trained persons who are familiar with and fully understand the contents of the present manual and all other pertinent product documentation and who have received all necessary training to recognize and avoid hazards involved are authorized to work on and with this equipment.
- Installation, adjustment, repair and maintenance must be performed by qualified personnel.
- Verify compliance with all local and national electrical code requirements as well as all other applicable regulations with respect to grounding of all equipment.
- Before performing work and/or applying voltage on the equipment, follow the instructions given in the appropriate installation manual.

Failure to follow these instructions will result in death or serious injury.

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this product. © 2023 Schneider Electric. All Rights Reserved.

Option Module		Altivar Machine			Altivar Process		Altivar Soft Starter	Lexium	MV Drive
		ATV32	ATV320	ATV340 (1)	ATV600 (2)	ATV900	ATS480	LXM32	ATV6000
		Device version \geq (Option Module version \geq)							
VW3A3601	EtherCAT	V1.2IE03 (V1.1IE08)	V2.7IE23 (V1.9IE09)	V1.1IE02 (V1.11IE01)		V1.2IE02 (V1.8IE05)		V1.4IE06 (V1.11IE08)	✓
VW3A3607	PROFIBUS DP	V1.1IE01 (V1.5IE01)	V2.7IE23 (V1.12IE01)	V1.1IE02 (V1.12IE01)	V1.1IE01 (V1.9IE01)	V1.1IE01 (V1.10IE01)	V1.1IE01 (V1.16IE08)	V1.0IE03 (V1.3IE01)	✓
VW3A3608 VW3A3618 VW3A3628	CANopen	V1.2IE03 (V1.1IE01)	V2.7IE23 (V1.1IE01)	V1.1IE02 (V1.1IE01)	V1.1IE01 (V1.1IE01)	V1.1IE01 (V1.1IE01)	V1.1IE01 (V1.1IE01)	V1.0IE03 (✓)	✓
VW3A3609	DeviceNet	V1.1IE01 (V1.1IE01)	V2.7IE23 (V1.8IE01)	V1.1IE02 (V1.8IE01)	V1.1IE01 (V1.5IE05)	V1.1IE01 (V1.5IE05)			✓
VW3A3616	Ethernet TCP/IP	V1.1IE01 (V1.2IE01)	V2.7IE23 (V1.EIE01)					V1.0IE03 (V1.11IE31)	
VW3A3619	POWERLINK	V1.5IE08 (V1.0IE08)	V2.7IE23 (V1.0IE08)	V1.5IE10 (V1.1IE04)	V2.2IE24 (V1.1IE04)	V1.8IE14 (V1.1IE04)			
VW3A3627	PROFINET	V1.8IE11 (V1.0IE15)	V2.7IE23 (V1.6IE01)	V1.1IE02 (V1.6IE01)	V1.1IE01 (V1.3IE01)	V1.1IE01 (V1.3IE01)			✓
VW3A3647	PROFINET + S2 Redundancy				V3.8 (\geq V3.0IE20)	V3.9 (\geq V3.0IE20)			
VW3A3720	Ethernet IP / Modbus TCP				V1.5IE11 (V1.8IE12) (3)		V1.1IE01 (V2.1IE00)		
VW3A3721	Ethernet IP / Modbus TCP + MultiDrive Link				V1.6IE12 (V1.8IE13) (3)				
VW3A3725	BACnet MS/TP				V1.7IE16 (V1.1IEXX)				
VW3M3301	DeviceNet							\geq V1.0IE03 \leq V1.20IE05 (V1.0)	
VW3M3308	PROFINET							V1.24IE03 (V1.0IE11)	
VW3A3530D	ATV dPAC Module			For the Altivar Firmware Version, contact your Schneider Electric Customer Care Center on www.se.com/CCC					


(1) Fieldbus modules can not be used on the ATV340****N45 and ATV340****N4E \leq 22kW. For more information, see the ATV340 Installation Manual (NVE61069).

(2) ATV610 is compatible only with VW3A3607 PROFIBUS DP fieldbus module.


(3) Drive version \geq V2.2IE24 is only compatible with module version \geq V1.15IE18.

ATV320 ATV32


Mounting






1)




2)






3)



4)




5)




ATV320 ATV32


Removing





1) 




2) 



3) 





ATV320






Mounting



NVE22661



VW3A3600







Removing

LXM32M ATV340


Mounting




1 





Slot 1 
Slot 2 
Slot 3 






GP-SF 
GP-ENC 
GP-FB 


2 



3 




4 




Removing



1 




2 






3 







1)




2)





3)














4)




5)








1)



2)



3)

