


VX5VPM002

wear part - enclosure door fan for variable speed drive IP21 and IP54



Main

Range of product	Altivar Process ATV600 Altivar Process ATV900
Accessory / separate part type	Fan kit
Accessory / separate part category	Cooling accessory

Complementary

Kit composition	Mounting bracket Instruction sheet Fan
Product compatibility	Variable speed drive ATV630 floor-standing 110 kW 380...440 V Variable speed drive ATV630 floor-standing 132 kW 380...440 V Variable speed drive ATV630 floor-standing 160 kW 380...440 V Variable speed drive ATV630 floor-standing 200 kW 380...440 V Variable speed drive ATV630 floor-standing 250 kW 380...440 V Variable speed drive ATV630 floor-standing 315 kW 380...440 V Variable speed drive ATV650 floor-standing 110 kW 380...440 V Variable speed drive ATV650 floor-standing 132 kW 380...440 V Variable speed drive ATV650 floor-standing 160 kW 380...440 V Variable speed drive ATV650 floor-standing 200 kW 380...440 V Variable speed drive ATV650 floor-standing 250 kW 380...440 V Variable speed drive ATV650 floor-standing 315 kW 380...440 V Variable speed drive ATV930 floor-standing 110 kW 380...440 V Variable speed drive ATV930 floor-standing 132 kW 380...440 V Variable speed drive ATV930 floor-standing 160 kW 380...440 V Variable speed drive ATV930 floor-standing 200 kW 380...440 V Variable speed drive ATV930 floor-standing 250 kW 380...440 V Variable speed drive ATV930 floor-standing 315 kW 380...440 V Variable speed drive ATV950 floor-standing 110 kW 380...440 V Variable speed drive ATV950 floor-standing 132 kW 380...440 V Variable speed drive ATV950 floor-standing 160 kW 380...440 V Variable speed drive ATV950 floor-standing 200 kW 380...440 V Variable speed drive ATV950 floor-standing 250 kW 380...440 V Variable speed drive ATV950 floor-standing 315 kW 380...440 V

Environment

The information provided in this documentation contains general descriptions and/or technical characteristics of the products contained herein. This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications. It is the duty of any such user or integrator to perform the appropriate and complete risk analysis, evaluation and testing of the products with respect to the relevant specific application or use thereof. Neither Schneider Electric Industries SAS nor any of its affiliates or subsidiaries shall be responsible or liable for misuse of the information contained herein.